

**NAME**

foo2zjs-wrapper – Convert Postscript into a ZJS printer stream

**SYNOPSIS**

**foo2zjs-wrapper** [*options*] [*ps-file*]

**DESCRIPTION**

**foo2zjs-wrapper** is a Foomatic compatible printer wrapper for the **foo2zjs** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-c**      Print in color (else monochrome).

**-C** *colormode*

Color correction mode [0].

- 0    Best compromise
- 1    Photos (using m2300w CRDs)
- 2    Photos and text (using m2300w CRDs)
- 3    Graphics and text (using m2300w CRDs)
- 10   ICM color profile (using -G \*.icm file)

**-d** *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

**-m** *media*

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

**-p** *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

- n** *copies*  
Number of copies [1].
- r** *xresxyres*  
Set device resolution in pixels/inch [1200x600].
- s** *source*  
Source (Input Slot) code to send to printer [7].
 

1	upper	4	manual
2	lower	7	auto
- t** Draft mode. Every other pixel is white.
- 2** Print in 2-up. Requires the **psutils** package.
- 4** Print in 4-up. Requires the **psutils** package.
- o** *orient*  
Orientation used for N-up.
 

Portrait	<b>-op</b>	(normal)
Landscape	<b>-ol</b>	(rotated 90 degrees anticlockwise)
Seascape	<b>-os</b>	(rotated 90 degrees clockwise)

### Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

- u** *xoff xyoff*  
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l** *xoff xyoff*  
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L** *mask*  
Send the logical clipping values from -u/-l in the ZjStream. **foo2zjs-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.
  - 0 don't send any logical clipping amounts
  - 1 only send Y clipping amount
  - 2 only send X clipping amount
  - 3 send both X and Y clipping amounts
- P** Do not send START\_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.
- X** *padlen*  
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.
- z** *model*  
Model: 0=2300DL, 1=HP1020. Default is 0.

### Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

**-g** *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

**-G** *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

**-G** *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:  
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

**-I** *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

**Debugging Options**

These options are used for debugging **foo2zjs** and its wrapper.

**-S** *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

**-D** *level*

Set Debug level [0].

**EXAMPLES**

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2zjs-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2zjs-wrapper -c testpage.ps > testpage.zc
```

**FILES**

**/usr/bin/foo2zjs-wrapper**

**SEE ALSO**

**foo2zjs(1)**, **zjsdecode(1)**

**AUTHOR**

Rick Richardson <rickr@mn.rr.com>  
<http://foo2zjs.rkkda.com/>

**NAME**

foo2zjs – Convert Ghostscript pbmraw or bitcmyk format into a ZJS printer stream

**SYNOPSIS**

**foo2zjs** [*options*] <*pbmraw-file*> *zjs-file*

**foo2zjs** [*options*] <*bitcmyk-file*> *zjs-file*

**foo2zjs** [*options*] <*pksmraw-file*> *zjs-file*

**DESCRIPTION**

**foo2zjs** converts Ghostscript pbmraw, bitcmyk, or pksmraw output formats to monochrome or color ZJS streams, for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-c** Force color mode if autodetect doesn't work.

**-d** *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

**-g** *xpixxypix*

Set page dimensions in pixels [10200x6600].

**-m** *media*

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

**-p** *paper*

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

**-n** *copies*

Number of copies [1].

**-r** *xresxyres*

Set device resolution in pixels/inch [1200x600].

**-s** *source*  
Source (InputSlot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

**-t** Draft mode. Every other pixel is white.

**-J** *filename*  
Filename string to send to printer.

**-U** *username*  
Username string to send to printer.

### Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

**-u** *xoff* *xyoff*  
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

**-l** *xoff* *xyoff*  
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

**-L** *mask*  
Send logical clipping amounts implied by -u/-l in the ZjStream [3].

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

**-P** Do not send START\_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.

**-A** AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmk input only.

**-B** BlackClears: K=1 forces C,M,Y to 0. Works with bitcmk input only.

**-X** *padlen*  
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

**-z** *model*  
Model: 0=2300DL, 1=HP1020. Default is 0.

### Debugging Options

These options are used for debugging **foo2zjs**.

**-S** *plane*  
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

**-D** *level*  
Set Debug level [0].

### EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r1200x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g10200x6600 -r1200x600 -sDEVICE=bitcmyk
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zc
```

## FILES

`/usr/bin/foo2zjs`

## SEE ALSO

`foo2zjs-wrapper(1)`, `zjsdecode(1)`

## AUTHOR

Rick Richardson <[rickr@mn.rr.com](mailto:rickr@mn.rr.com)>  
<http://foo2zjs.rkkda.com/>

**NAME**

zjsdecode – Decode a ZjStream into human readable form.

**SYNOPSIS**

**zjsdecode** [*options*] <*zjs-file*

**DESCRIPTION**

**zjsdecode** decodes a ZjStream into human readable form.

A ZjStream is the printer language used by some Minolta/QMS and HP printers, such as the 2300DL and LJ-1000.

More information on Zenographics ZjStream can be found at:

<http://ddk.zeno.com>

**COMMAND LINE OPTIONS**

These are the options that can appear on the command line.

**-d** *basename*

Basename of .pbm file for saving decompressed planes.

**-r** *basename*

Basename of .jbg file for saving raw planes

**-h** Print hex file offsets.

**-o** Print file offsets.

**-D** *level*

Set Debug level [0].

**EXAMPLES**

Decode an ZjStream file created by foo2zjs.

```
$ zjsdecode < testpage.zm
ZJT_START_DOC, 3 items
    ZJI_PAGECOUNT, 0 (0x0)
    ZJI_DMDUPLEX, 1 (0x1)
    ZJI_QUANTITY, 1 (0x1)
ZJT_START_PAGE, 17 items
    ZJI_0x17, 0 (0x0)
    ZJI_0x16, 1 (0x1)
    ZJI_VIDEO_X, 10200 (0x27d8)
    ZJI_VIDEO_Y, 6600 (0x19c8)
    ZJI_VIDEO_BPP, 1 (0x1)
    ZJI_RASTER_X, 10200 (0x27d8)
    ZJI_RASTER_Y, 6600 (0x19c8)
    ZJI_OFFSET_X, 0 (0x0)
    ZJI_OFFSET_Y, 0 (0x0)
    ZJI_NBIE, 1 (0x1)
    ZJI_RESOLUTION_X, 1200 (0x4b0)
    ZJI_RESOLUTION_Y, 600 (0x258)
    ZJI_DMDEFAULTSOURCE, 7 (0x7)
    ZJI_DMCOPIES, 1 (0x1)
    ZJI_DMPAPER, 1 (0x1)
    ZJI_DMMEDIATYPE, 1 (0x1)
    ZJI_MINOLTA_PAGE_NUMBER, 1 (0x1)
```

```
ZJT_JBIG_BIH, 0 items
    Data: 20 bytes
        DL = 0, D = 0, P = 1, - = 0, XY = 10200 x 6600
        L0 = 128, MX = 16, MY = 0
        Order    = 3   ILEAVE SMID
        Options = 92   LRLTWO TPDON TPBON DPON
        52 stripes, 0 layers, 1 planes
ZJT_JBIG_BID, 0 items
    Data: 65536 bytes
ZJT_JBIG_BID, 0 items
    Data: 29120 bytes
ZJT_END_JBIG, 0 items
ZJT_END_PAGE, 0 items
ZJT_END_DOC, 0 items
```

**FILES**

/usr/bin/zjsdecode

**SEE ALSO**

**foo2zjs-wrapper(1)**, **foo2zjs(1)**, **jbg2pbm(1)**

**AUTHOR**

Rick Richardson <rickr@mn.rr.com>

<http://foo2zjs.rkkda.com/>



**NAME**

foo2oak-wrapper – Convert Postscript into an OAKT printer stream

**SYNOPSIS**

**foo2oak-wrapper** [*options*] [*ps-file*]

**DESCRIPTION**

**foo2oak-wrapper** is a Foomatic compatible printer wrapper for the **foo2oak** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Oak Technology OAKT printer format for driving the HP Color LaserJet 1500 laser printer and other OAKT-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-b** *bits* Number of bits per plane (1 or 2) [1].

**-c** Print in color (else monochrome).

**-m** *media*

Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

**-p** *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

**-n** *copies*

Number of copies [1].

**-r** *xresxyres*

Set device resolution in pixels/inch [600x600].

**-s** *source*

Source (Input Slot) code to send to printer [7].

1	upper	4	manual
7	auto		

**-2** Print in 2-up. Requires the **psutils** package.

**-4** Print in 4-up. Requires the **psutils** package.

**-o** *orient*

Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

## Printer Tweaking Options

These are the options used to customize the operation of **foo2oak** for a particular printer.

### **-u** *xoff* *xyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

### **-l** *xoff* *xyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

### **-L** *mask*

Send the logical clipping values from -u/-l in the OAKT stream. **foo2oak-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

## Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

### **-g** *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

### **-G** *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

### **-G** *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:

```
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer
```

### **-I** *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

## Debugging Options

These options are used for debugging **foo2oak** and its wrapper.

### **-S** *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

### **-D** *level*

Set Debug level [0].

**EXAMPLES**

Create a monochrome OAKT stream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2oak-wrapper testpage.ps > testpage.oak
oakdecode < testpage.oak
lpr -P raw testpage.oak
```

Create a color OAKT stream from a Postscript document:

```
foo2oak-wrapper -c testpage.ps > testpage.oak
```

**FILES**

**/usr/bin/foo2oak-wrapper**

**SEE ALSO**

**foo2oak(1), oak(1)**

**AUTHOR**

Rick Richardson <rickr@mn.rr.com>  
<http://foo2oak.rkkda.com/>

**NAME**

foo2oak – Convert Ghostscript pbmraw, pgmraw or bitcmk format into an OAKT printer stream

**SYNOPSIS**

**foo2oak** [*options*] <*pbmraw-file*> *OAKT-file*

**foo2oak** [*options*] <*pgmraw-file*> *OAKT-file*

**foo2oak** [*options*] <*bitcmk-file*> *OAKT-file*

**DESCRIPTION**

**foo2oak** converts Ghostscript pbmraw or bitcmk output formats to monochrome or color OAKT streams, for driving the HP color Laserjet 1500 laser printer and other OAKT-based printers.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-c** Force color mode if autodetect doesn't work.

**-g** *xpixxypix*  
Set page dimensions in pixels [10200x6600].

**-m** *media*  
Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

**-p** *paper*  
Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

**-n** *copies*  
Number of copies [1].

**-r** *xresxyres*  
Set device resolution in pixels/inch [600x600].

**-s** *source*  
Source (InputSlot) code to send to printer [7].

1	tray1	4	manual
7	auto		

**-J** *filename*  
Filename string to send to printer.

**-U** *username*  
Username string to send to printer.

**Printer Tweaking Options**

These are the options used to customize the operation of **foo2oak** for a particular printer.

- u** *xoff x y off*  
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].
- l** *xoff x y off*  
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].
- L** *mask*  
Send logical clipping amounts implied by -u/-l in the OAKT stream [3].
  - 0 don't send any logical clipping amounts
  - 1 only send Y clipping amount
  - 2 only send X clipping amount
  - 3 send both X and Y clipping amounts
- A** Turn off: conversion of C=1,M=1,Y=1 to pure black.
- B** Turn off: K=1 forces C,M,Y to 0.

### Debugging Options

These options are used for debugging **foo2oak**.

- S** *plane*  
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.
  - 1 Cyan
  - 2 Magenta
  - 3 Yellow
  - 4 Black
- D** *level*  
Set Debug level [0].

### EXAMPLES

Create a black and white OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

Create a color OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmk
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

### FILES

**/usr/bin/foo2oak**

### SEE ALSO

**foo2oak-wrapper(1)**, **oakdecode(1)**

### AUTHOR

Rick Richardson <rickr@mn.rr.com>  
<http://foo2oak.rkkda.com/>

**NAME**

oakdecode – Decode an OAKT printer stream into human readable form.

**SYNOPSIS**

**oakdecode** [*options*] <*OAKT-file*

**DESCRIPTION**

**oakdecode** decodes an OAKT printer stream into human readable form.

An OAKT printer stream is the printer language used by the HP Color LaserJet 1500 and other printers.

**COMMAND LINE OPTIONS**

These are the options that can appear on the command line.

- d** *basename*  
    Basename of .pbm file for saving decompressed planes.
- r** *basename*  
    Basename of .jbg file for saving raw planes
- i**     Suppress display of image records.
- o**     Print file offsets.
- D** *level*  
    Set Debug level [0].

**EXAMPLES**

Decode an OAKT file created by foo2oak.

```
$ oakdecode < testpage.oak
0d (80) 1 OTHER
0c (64) Wed Nov 05 16:30:50 2003          a07d3    100005    32001e
0a (80) testpage.pdf
14 (16) (no args)
28 (16) Source=Tray1
29 (80) PaperType=0 UNK8=2,0,0,0, blanks(63)
2a (32) Copies=1          UNK=0
2b (32) papercode=25      xwid=4648          ywid=9000          UNK=0
33 (64)
        u0      u1      w      h      resx      resy      nBits
        x0      x0      2128    4300    600      600      x1
15 (16) (no args)
        bih0      w      h      10      bih5      dlen      plen      unk      yOff      P      subP
3c (64) 00010000 2176  256  256 58030020 1050  1056 000    64 3 0
        DL = 0, D = 0, P = 1, - = 0, XY = 2176 x 256
        L0 = 256, MX = 32, MY = 0
        Order   = 3  ILEAVE SMID
        Options = 88  LRLTWO TPDON TPBON
        1 stripes, 0 layers, 1 planes
3c (64) 00010000 2176  256  256 58030020 3668  3680 000    320 3 0
3c (64) 00010000 2176  256  256 58030020 1463  1472 000    640 3 0
3c (64) 00010000 2176  256  256 58030020 1975  1984 000    896 3 0
3c (64) 00010000 2176  224  224 58030020 2744  2752 000   1152 3 0
3c (64) 00010000 2176  256  256 58030020   988    992 000   1440 3 0
3c (64) 00010000 2176  256  256 58030020 2892  2896 000   1696 3 0
3c (64) 00010000 2176  256  256 58030020 3634  3648 000   1952 3 0
```

```

3c (64) 00010000 2176 256 256 58030020 3236 3248 000 2208 3 0
3c (64) 00010000 2176 256 256 58030020 2279 2288 000 2464 3 0
3c (64) 00010000 2176 256 256 58030020 3746 3760 000 2720 3 0
3c (64) 00010000 2176 200 200 58030020 2404 2416 000 2976 3 0
3c (64) 00010000 2176 256 256 58030020 3114 3120 000 3240 3 0
3c (64) 00010000 2176 96 96 58030020 1142 1152 000 3496 3 0
3c (64) 00010000 2176 256 256 58030020 2094 2112 000 3752 3 0
3c (64) 00010000 2176 256 256 58030020 1319 1328 000 4008 3 0
3c (64) 00010000 2176 36 36 58030020 208 224 000 4264 3 0
17 (16) (no args)
18 (16) UNK=0
0b (16) (no args)

```

**FILES**

**/usr/bin/oakdecode**

**SEE ALSO**

**foo2oak-wrapper(1), foo2oak(1), jbg2pbm(1)**

**AUTHOR**

Rick Richardson <rickr@mn.rr.com>  
<http://foo2oak.rkkda.com/>

**NAME**

foo2hp2600-wrapper – Convert Postscript into a ZJS printer stream

**SYNOPSIS**

**foo2hp2600-wrapper** [*options*] [*ps-file*]

**DESCRIPTION**

**foo2hp2600-wrapper** is a Foomatic compatible printer wrapper for the **foo2hp** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-b** *bits* Number of bits per plane. 1 or 2. [1].

**-c** Print in color (else monochrome).

**-d** *duplex*

Duplex code to send to printer [1].

1	off	4	manual long edge	5	manual short edge
---	-----	---	------------------	---	-------------------

**-m** *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

**-p** *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5



7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

- n** *copies*  
Number of copies [1].
- r** *xresxyres*  
Set device resolution in pixels/inch [1200x600].
- s** *source*  
Source (Input Slot) code to send to printer [7].
 

1	tray 2	7	auto
2	tray 1		
- t** Draft mode. Every other pixel is white.
- 2** Print in 2-up. Requires the **psutils** package.
- 4** Print in 4-up. Requires the **psutils** package.
- o** *orient*  
Orientation used for N-up.
 

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

### Printer Tweaking Options

These are the options used to customize the operation of **foo2hp** for a particular printer.

- u** *xoffxyoff*  
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l** *xoffxyoff*  
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L** *mask*  
Send the logical clipping values from -u/-l in the ZjStream. **foo2hp2600-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.
 

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts
- P** Do not send START\_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.
- X** *padlen*  
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

### Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

**-g** *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

**-G** *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. If *profile.icm* is none.icm, then prepare for ordering a ICM custom printer profile (i.e. from [www.ICCFactory.com](http://www.ICCFactory.com)).

**-G** *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:  
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

**-I** *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

### Debugging Options

These options are used for debugging **foo2hp** and its wrapper.

**-S** *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

**-D** *level*

Set Debug level [0].

### EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2hp2600-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2hp2600-wrapper -c testpage.ps > testpage.zc
```

### FILES

**/usr/bin/foo2hp2600-wrapper**

### SEE ALSO

**foo2hp(1)**, **zjsdecode(1)**

### AUTHOR

Rick Richardson <[rickr@mn.rr.com](mailto:rickr@mn.rr.com)>  
<http://foo2hp.rkkda.com/>

**NAME**

foo2hp – Convert Ghostscript pbmraw or bitcmyk format into a ZJS printer stream

**SYNOPSIS**

**foo2hp** [*options*] <*pbmraw-file*> *zjs-file*

**foo2hp** [*options*] <*bitcmyk-file*> *zjs-file*

**foo2hp** [*options*] <*cups-file*> *zjs-file*

**DESCRIPTION**

**foo2hp** converts Ghostscript pbmraw, bitcmyk, or cups output formats to monochrome or color ZJS streams, for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

**COMMAND LINE OPTIONS****Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

**-b** *bits* Bits per plane if autodetect doesn't work (1 or 2) [1].

**-c** Force color mode if autodetect doesn't work.

**-d** *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
		4	manual " "	5	manual " "

**-g** *xpixxypix*

Set page dimensions in pixels [10200x6600].

**-m** *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

**-p** *paper*

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

**-n** *copies*

Number of copies [1].

**-r** *xresxyres*

Set device resolution in pixels/inch [600x600].

**-s** *source*

Source (InputSlot) code to send to printer [7].

1	tray 2	7	auto
2	tray 1		

**-t** Draft mode. Every other pixel is white.

**-J** *filename*

Filename string to send to printer.

**-U** *username*

Username string to send to printer.

**Printer Tweaking Options**

These are the options used to customize the operation of **foo2hp** for a particular printer.

**-u** *xoffxyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

**-l** *xoffxyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

**-L** *mask*

Send logical clipping amounts implied by -u/-l in the ZjStream [3].

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

**-P** Do not send START\_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.

**-A** AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmk input only.

**-B** BlackClears: K=1 forces C,M,Y to 0. Works with bitcmk input only.

**-X** *padlen*

Add extra zero padding to the end of BID segments. The default is 16 bytes.

**Debugging Options**

These options are used for debugging **foo2hp**.

**-S** *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan

- 2   Magenta
- 3   Yellow
- 4   Black

**-D** *level*

Set Debug level [0].

## EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmk
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zc
```

## FILES

**/usr/bin/foo2hp**

## SEE ALSO

**foo2hp2600-wrapper(1)**, **zjsdecode(1)**

## AUTHOR

Rick Richardson <rickr@mn.rr.com>  
<http://foo2hp.rkkda.com/>

